

ViewSonic Board

The ViewSonic ViewBoard is a multi-faceted interactive display and touch screen.



Turn on the ViewSonic ViewBoard.




Use the pen as the touch tool to avoid making finger marks on the screen.




Replace the pen on the magnetic pad when finished with it.

Connect to the ViewBoard using the attached cables.





Specifically, you will need the HDMI cable and the USB cable.
Insert each cable in the corresponding port of your laptop.



The USB cable will sync your laptop touchpad with the ViewBoard .

Select HDMI in the ViewBoard settings if the ViewBoard does not sync the video output with your laptop.



Additionally, check your laptop display settings to make sure that your laptop is set to clone its display.